

OF NEW MEXICO
MINERALS DEPARTMENT

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

COPIES RECEIVED	
DISTRIBUTION	
DATE	
BY	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-1113-1

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name Central Vacuum Unit
2. Name of Operator TEXACO Inc.	8. Farm or Lease Name Central Vacuum Unit
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240	9. Well No. 98
4. Location of Well UNIT LETTER D, 660 FEET FROM THE North LINE AND 484 FEET FROM THE West LINE, SECTION 6 TOWNSHIP 18-S RANGE 35-E NMPM.	10. Field and Pool, or Wildcat Vacuum Grayburg San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 3986' (GR)	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> OTHER <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> OTHER <input type="checkbox"/>
REMEDIAL WORK <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> CASING TEST AND CEMENT JOBS <input type="checkbox"/> OTHER <input checked="" type="checkbox"/> Temporarily Abandon & Establish Monitor Well, at requested by MOCOD	
ALTERING CASING <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Cut Reda Cable & 2 7/8" tubing @ 4250'.
2. Plug back with 96 sx. sand to 4250'.
3. Spot 200 sx. Cement plug from 4250'-2950'.
4. Cut Reda Cable & tubing @ 1730' & pull same.
5. Set Cement retainer @ 1283'. Squeeze casing leak @ 1283' w/250 sx. class 'H' Cement. Did not circulate. No Flow.
6. Install well head equipment. Monitor well, effective 3-31-83. Well will be plugged and abandoned at a later date.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Mgr. DATE 9-20-83

ORIGINAL SIGNED BY JERRY SEXTON
APPROVED BY DISTRICT SUPERVISOR TITLE _____ DATE SEP 22 1983
CONDITIONS OF APPROVAL, IF ANY:

RECEIVED
SEP 21 1983
C. C. C.
HOBBS OFFICE