

URGENT

PLUGGING PROGRAM - J. P. REEVES--WELL NO.

REC'D
APR 23 1945

Spot a plug of 45 sacks of cement from 5655' to approximately 5535' to shut off water; 20 sacks, 5350-5300'; 30 sacks, 3450-3370 (at base of salt), and 30 sacks, 1870-1800' (at top of salt and in bottom of 9-5/8" casing). Part and pull all possible 9-5/8" casing (estimated 700-800'). Spot 30 sacks of cement in bottom of 13-3/8" casing, from approximately 315' to 275'. The customary 4" pipe marker will be cemented in the top of the hole with 20 sacks, leaving all 13-3/8" casing cemented in the hole.
