

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUBMIT IN TRI
(Other instructions
verse side)

Ferm approved.
Budget Bureau No. 42-R-1

5. LEASE DESIGNATION AND SERIAL NO.

LC 032233(2)

6. IF INDIAN, ALLOTTEE OR ARRE NAGA

SUNDY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT" for such proposals.)

1.

OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR

Humble Oil & Refg Co

3. ADDRESS OF OPERATOR

Box 1600 Midland Texas 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.*
See also space 17 below)
At surface

2310' FNL, 990' FWL

14. PERMIT NO.

15. ELEVATIONS (Show whether EX, RT, OR, etc.)

3656 DF

10. FIELD AND POOL, OR WILDCAT

HOODS L.P.H.
Bowers Rivers

11. SEC., T., R., M., OR BLM. AND
SURVEY OR AREA

S 29, T 18S, R 38E

12. COUNTY OR PARISH 13. STATE

Lea

N.M.

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETION

ABANDON*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT*

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting and proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

Permission is requested to plug and abandon well as follows:

1. Set cement plug from 3000-3250' w/ 50 sack cement.
2. Set cement plug from 1700-1900' w/ 50 sack cement, if no casing salvage or across casing stub w/ 50 sack if casing salvage.
3. Set cement plug from 25' to surface w/ 10 sack
4. Install dry hole marker and clean location.
5. Mud laden fluid between plugs.

- ADDITIONAL:**
1. Set additional 20-sack cement plug at 2,350-2,450 feet.
 2. Set 50 sack cement plug at 1400-1600 feet if no casing salvageable, or across casing stub if higher than 1,300 feet. This plug may be substituted for plug No. 2 above if desired.

18. I hereby certify that the foregoing is true and correct

SIGNED

James L. C.

TITLE

Unit Head

DATE

1/17/70

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side

APPROVED
AS AMENDED
JAN 22 1970
C/K
ARTIFICIAL BROWN