

UNITED STATES
DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT

WELL LOG

1. NAME OF WELL AND LOCATION

12. OTHER DATA

13. DATE OF LOGGING

14. NAME OF LOGGERS

15. NAME OF LOGGERS

16. NAME OF LOGGERS

17. NAME OF LOGGERS

18. NAME OF LOGGERS

19. NAME OF LOGGERS

20. NAME OF LOGGERS

21. NAME OF LOGGERS

22. NAME OF LOGGERS

SUMMARY NOTICE AND REPORT ON WELLS

(This form is to be filled out by the well owner or operator and submitted to the Bureau of Land Management, Department of the Interior, Washington, D.C. 20540.)

1. NAME OF WELL AND LOCATION

2. NAME OF OPERATOR

3. NAME OF OPERATOR

4. NAME OF OPERATOR

5. NAME OF OPERATOR

6. NAME OF OPERATOR

7. NAME OF OPERATOR

8. NAME OF OPERATOR

9. NAME OF OPERATOR

10. NAME OF OPERATOR

11. NAME OF OPERATOR

12. NAME OF OPERATOR

13. NAME OF OPERATOR

14. NAME OF OPERATOR

15. NAME OF OPERATOR

16. NAME OF OPERATOR

17. NAME OF OPERATOR

18. NAME OF OPERATOR

19. NAME OF OPERATOR

20. NAME OF OPERATOR

21. NAME OF OPERATOR

22. NAME OF OPERATOR

23. NAME OF OPERATOR

24. NAME OF OPERATOR

25. NAME OF OPERATOR

26. NAME OF OPERATOR

27. NAME OF OPERATOR

28. NAME OF OPERATOR

29. NAME OF OPERATOR

30. NAME OF OPERATOR

31. NAME OF OPERATOR

32. NAME OF OPERATOR

33. NAME OF OPERATOR

34. NAME OF OPERATOR

35. NAME OF OPERATOR

36. NAME OF OPERATOR

37. NAME OF OPERATOR

38. NAME OF OPERATOR

39. NAME OF OPERATOR

40. NAME OF OPERATOR

41. NAME OF OPERATOR

42. NAME OF OPERATOR

43. NAME OF OPERATOR

44. NAME OF OPERATOR

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENT TO PLUG

STANDARD REPORT ON

TEST WATER SHUT-OFF

PULL OR ALTER CASING

WATER SHUT-OFF

REPAIRING WELL

FRACURE TOFAN

MAINTAIN COMPLETE

FRACURE TOFAN

ALTERING CASING

SHOOT OR ACCIDENT

ABANDON

SHOOTING OR ACCIDENT

ABANDONMENT

REPAIR WELL

CHANGE PLANS

(Other)

(Other)

(Note: Report on all multiple completion on Well Completion or on the completion of the well.)

17. DESCRIBE THE PLUGGING OPERATION, INCLUDING THE TYPE OF PLUG, THE DATE OF PLUGGING, AND THE NAME OF THE OPERATOR. (If the well is plugged, give the surface location and measured and true vertical depths for all markers and zones plugged to this well.)

1. Notify USGS, CCC and other operators of intent to plug & abandon.

2. Pull rods and tubing with CH packers out of hole. Lay rods down and rerun tubing open ended.

3. Displace hole with gel mud.

4. Spot cement plugs as follows:
From T. D. to 3930' with 75 sacks (San Andres)
From 3900' to 3700' with 25 sacks (Byers)
From 3350' to 3150' with 50 sacks (Bowers)
From 2800' to 2700' with 25 sacks (Yates)
Follow each plug with gel mud
From 250' to Surface with 60 sacks (Gallala & surface plug)

5. Remove wellhead and install marker.

AMENDMENT: If 7" casing can be pulled place additional 100 foot cement plug in 9-5/8" casing at 1400-1500 feet.
If 7" casing cannot be pulled place 100 foot cement plug inside 7" casing in the interval 1400 to 1500 feet.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE District Superintendent

DATE September 22, 1971

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

DEC 14 1971

ARTHUR R. BROWN
DISTRICT ENGINEER

*See Instructions on Reverse