

It is proposed to plug and abandon well as follows:

- 1. Rig up; pull tubing and set CIBP at 3100+. Dump 35' of cement on top of CIBP.
- 2. Circulate hole with mud. (7.5# brine with 25 sk/100 bbl. salt gel).
- 3. Run tubing and spot a 100' cement plug @ 1474'. (5-1/2" casing and 8-5/8" casing is cemented to surface. Top of salt is at 1680'.)
- 4. Set a 10 sack cement surface plug.
- 5. Set marker and clean up location.

entries and the information above as a complete the

AREA SUPERINTENDENT

MAY 14, 1975

45.5	C. L.	Wade: p-	2		÷1.
				ierre i i i-	
				Brig. Signed b	ÿ
- 2 in				he D. Kane	
	s .	- POVIC, P	4 ·	Dist. 1, Sugar	•

HAO/bh