

OIL CONSERVATION DIVISION

P. O. BOX 2088  
SANTA FE, NEW MEXICO 87501

Form C-103  
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease  
State ☐ Fee ☒  
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.  
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name N. HOBBS (G/SA) UNIT
2. Name of Operator SHELL OIL COMPANY	8. Farm or Lease Name SECTION 31
3. Address of Operator P. O. BOX 991, HOUSTON, TEXAS 77001	9. Well No. 321
4. Location of Well UNIT LETTER G 2200 FEET FROM THE NORTH LINE AND 2310 FEET FROM THE EAST LINE, SECTION 31 TOWNSHIP 18-S RANGE 38-E NMPM.	10. Field and Pool, or Wildcat HOBBS (G/SA)
15. Elevation (Show whether DF, RT, GR, etc.) 3644' GR	12. County LEA

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data  
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER REPAIR CASING LEAK AND ACID TREAT <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1503.

- Set RBP @ 3900' + and FBRC @ 3800'. Test RBP, FBRC and tubing to 100 psi. Reset FBRC @+ 120' intervals and test each setting to 500 psi. Locate casing leaks.
- Spot 15' sand on RBP. Squeeze casing leaks below a cement retainer.
- Drill out cement retainer and cement, testing at 60' intervals. Re-squeeze any interval that will not test.
- Reverse off sand and retrieve BP.
- Acidize open hole with 3000 gals 15% HCL - NEA.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED A. J. FORE TITLE SUPERVISOR REG. & PERMITTING DATE MARCH 30, 1982

ORIGINAL SIGNED BY

APPROVED BY JERRY SEXTON TITLE \_\_\_\_\_ DATE APR 2 1982

CONDITIONS OF APPROVAL