

Submit 3 Copies  
to Appropriate  
District Office

DISTRICT I  
P.O. Box 1980, Hobbs, NM 88240

DISTRICT II  
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

OIL CONSERVATION DIVISION  
P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name N. HOBBS (G/SA) UNIT SECTION 32
8. Well No. 112
9. Pool name or Wildcat HOBBS (G/SA)
10. Elevation (Show whether DF, RKB, RT, GR, etc.) 3642' DF

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
OIL WELL ☐ GAS WELL ☐ OTHER INJECTOR

2. Name of Operator  
SHELL WESTERN E&P INC.

3. Address of Operator  
P. O. BOX 576, HOUSTON, TX 77001 (WCK 4435)

4. Well Location  
Unit Letter E : 1370 Feet From The NORTH Line and 330 Feet From The WEST Line

Section 32 Township 18S Range 38E NMPM LEA County

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data	
NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
OTHER: <u>SET CSG PATCH</u> <input checked="" type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
	CASING TEST AND CEMENT JOB <input type="checkbox"/>
	OTHER: <input type="checkbox"/>

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. PT tbg/csg ann to 300#.
2. POH w/inj equip.
3. CO to 4226' (PBTD).
4. RIH w/API drift gauge for 5" 15# lnr to 4150'. POH.
5. RIH w/30' of 4" wash pipe to ensure doglegs will not restrict running of patch.
6. RIH w/20' csg patch assy for 5" lnr. Set csg patch from 4088' to 4108'.
7. Install inj equip, setting Guib Uni-VI Pkr @ 4016'.
8. PT csg to 300# for 30 min.
9. Ret well to inj.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE W. F. N. Kelldorf TITLE SR. STAFF PRODUCTION ENGR. DATE 3-14-90

TYPE OR PRINT NAME W. F. N. KELLDORF (713) 870-3797 TELEPHONE NO.

(This space for State Use)

Orig. Signed by  
Paul Kautz  
Geologist

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

MAR 19 1990