

H. H. GIL 1982
P. O. BOX
MIDLAND, TEXAS

UNITED STATES
DEPARTMENT OF THE INTERIOR
GEOLOGICAL SURVEY

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir. Use Form 9-331-C for such proposals.)

1. oil ☐ well gas ☐ well other Water Injection
2. NAME OF OPERATOR
Cities Service Company
3. ADDRESS OF OPERATOR
P.O. Box 1919 - Midland, Texas 79702
4. LOCATION OF WELL (REPORT LOCATION CLEARLY. See space 17 below.) 1980' FSL & 1980' FEL
AT SURFACE: Same as above
AT TOP PROD. INTERVAL: Same as above
AT TOTAL DEPTH: Same as above
16. CHECK APPROPRIATE BOX TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA

REQUEST FOR APPROVAL TO: SUBSEQUENT REPORT OF:

- | | | |
|-----------------------------------|--------------------------|--------------------------|
| TEST WATER SHUT-OFF | ☐ | ☐ |
| FRACTURE TREAT | ☐ | ☐ |
| SHOOT OR ACIDIZE | ☐ | ☐ |
| REPAIR WELL | ☐ | ☐ |
| PULL OR ALTER CASING | ☐ | ☐ |
| MULTIPLE COMPLETE | ☐ | ☐ |
| CHANGE ZONES | ☐ | ☐ |
| ABANDON* | ☐ | ☐ |
| (other) Reactivate Injection Well | | |

5. LEASE LC-060967	
6. IF INDIAN, ALLOTTEE OR TRIBE NAME	
7. UNIT AGREEMENT NAME SMGSAU	
8. FARM OR LEASE NAME Tract 1	
9. WELL NO. 1	
10. FIELD OR WILDCAT NAME Maljamar (G-SA)	
11. SEC., T., R., M., OR BLK. AND SURVEY OR AREA Sec. 30-T17S-R33E	
12. COUNTY OR PARISH Lea	13. STATE New Mexico
14. API NO. N.A.	
15. ELEVATIONS (SHOW DF, KDB, AND WD) 4057' GR	

(NOTE: Report results of multiple completion or zone change on Form 9-330.)

3 3 1982

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)*

O.T.D. 4281' Lime, O.P.B.T.D. 4280'. It is proposed to reactivate this well in the following manner:

1. MIRU pulling unit and pull tubing.
2. Run casing scraper on tubing and CO to PBTD of 4280'. Pull tubing.
3. Run tubing w/packer @ approx. 4040' and acidize Perfs 4197-4249' w/ 5000 gals 20% HCL acid + 600# salt.
4. SI well for 30 minutes. Back flow and recover load.
5. ND BOP NU wellhead and hook up injection line and establish injection rate.

Subsurface Safety Valve: Manu. and Type _____ Set @ _____ Ft.

18. I hereby certify that the foregoing is true and correct

SIGNED Edman Stantz TITLE Region Opr. Mgr. Prod. DATE 2-24-82

APPROVED (This space for Federal or State office use)	
APPROVED BY (Orig. Sgd.) <u>DEWEY W. CHESTER</u>	TITLE _____ DATE _____
CONDITIONS OF APPROVAL, IF ANY:	
MAR 4 1982	
FOR JAMES A. GILLHAM DISTRICT SUPERVISOR	

*See Instructions on Reverse Side

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well site conditioned for final inspection looking to approval of the abandonment.

GPO : 1976 O - 214-149

RECEIVED

MAY 15 1982

WATER DIVISION