

INSTRUCTIONS FOR DRILLING OF WELL

- . Keep hole full at all times.
- . If sticking conditions occur, do not pull over half the weight of the drill string past its total weight before contacting company man.
- . Check recorder daily and make sure it is recording all pens accurately.
- . Be sure all fires and lights are out while drill stem testing.
- . Fill out AAODC report completely, enter all mud used, see that break down of hours is complete and accurate.
- . Do not waste water or mud, both items are very expensive. See that mud is stacked orderly at all times, if a sack is broken, use it the first opportunity.
- . If unusual conditions are noticed with the hole, be sure the company man, tool pusher and all drillers are notified.
- . Use blackboard or tablet to leave any information or orders on.
- . Check blow out equipment daily, do not let water accumulate in closing unit or lines.
- . Drilling from 2800' to intermediate point don't use float in drill pipe.
- . From 2800' to intermediate point reduce lowering drill pipe into hole rate to one minute stand.

113