

INSTRUCTIONS FOR DRILLING OF WELL

1. Keep hole full at all times.
2. If sticking conditions occur, do not pull over half the weight of the drill string past its total weight before contacting company man.
3. Check recorder daily and make sure it is recording all pens accurately.
4. Be sure all fires and lights are out while drill stem testing.
5. Fill out AAODC report completely, enter all mud used, see that break down of hours is complete and accurate.
6. Do not waste water or mud, both items are very expensive. See that mud is stacked orderly at all times, if a sack is broken, use it the first opportunity.
7. If unusual conditions are noticed with the hole, be sure the company man, tool pusher and all drillers are notified.
8. Use blackboard or tablet to leave any information or orders on.
9. Check blow out equipment daily, do not let water accumulate in closing unit or lines.
10. Drilling from 2800' to intermediate point don't use float in drill pipe.
11. From 2800' to intermediate point reduce lowering drill pipe into hole rate to one minute stand.