

NEW MEXICO OIL CONSERVATION COMMISSION

NO. OF COPIES RECEIVED		
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
OPERATOR		

5a. Indicate Type of Lease
 State Fee

5. State Oil & Gas Lease No.
B-3936-1

SUNDRY NOTICES AND REPORTS ON WELLS
 DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO RE-OPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
 USE APPLICATION FOR PERMIT (FORM C-101) FOR SUCH PROPOSALS.

1. OIL WELL GAS WELL OTHER

2. Name of Operator
TEXACO Inc.

3. Address of Operator
P.O. Box 728 Hobbs, New Mexico 88240

4. Location of Well
 UNIT LETTER **B** **660** FEET FROM THE **North** LINE AND **1980** FEET FROM
 THE **East** LINE, SECTION **10** TOWNSHIP **18-S** RANGE **34-E** N.M.P.M.

15. Elevation (Show whether DF, RT, GR, etc.)
4031' (DF)

7. Unit Agreement Name
 -

6. Farm or Lease Name
NM"AA" St. NCT-4

9. Well No.
3

10. Field and Pool, or Wildcat
Vacuum Abo Reef

12. County
Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

- Rigged Up.
- Set CIBP @ 8700' and dump 35' cement on plug.
- Cut 2-7/8" OD Csg @ 4560' and pulled.
- Spot 70 sx cement plug from 4550'-4350'.
- Spot 70 sx cement plug from 3880'-3310'.
- Spot 30 sx cement plug from 2942'-2842'.
- Spot 35 sx cement plug from 1742'-1642'.
- Cut 8-5/8" OD Csg @ 865' & pulled 28 Jts.
- Spot 100 sx cement plug from 905'-815'.
- Spot 100 sx cement plug from 410'-310'.
- Spot 5 sx cement plug at surface.
- Install dry hole marker and clean up. Well P&A 4-15-77.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE Asst. Dist. Supt. DATE 4-29-77

APPROVED BY *[Signature]* TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: