

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1031	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" FORM C-1011 FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER	7. Unit Agreement Name
2. Name of Operator	Central Vacuum Unit
3. Address of Operator	Central Vacuum Unit
P. O. Box 728, Hobbs, New Mexico 88240	9. Well No.
4. Location of Well	117
UNIT LETTER <u>D</u> <u>990</u> FEET FROM THE <u>South</u> LINE AND <u>23.0</u> FEET FROM	10. Field and Pool, or Wildcat
THE <u>East</u> LINE, SECTION <u>6</u> TOWNSHIP <u>12-S</u> RANGE <u>35-E</u> NMPM.	Vacuum Grayburg
	San Andres
15. Elevation (Show whether DF, RT, GR, etc.)	12. County
3980' (DF)	Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	OTHER <u>Repair Water Flow & Treat</u> <input checked="" type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rigged up. Pull rods, pump & tubing.
2. Set RBP @ 4009'. Perforate 3 1/2" Csg w/2-JS @ 1580'. Set cement retainer @ 1437'. Cement perms. @ 1580' w/425 sx. class 'H' cement. Cement circulated. Squeeze 75 sx. WOC. DOC. Tested OK.
3. Install pumping equipment. Test & return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Supt. DATE 3/5/81

APPROVED BY _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: