

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.
E 7723

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG DATA TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT TO DRILL" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER
2. Name of Operator Texas Pacific Oil Company, Inc.
3. Address of Operator P. O. Box 4067, Midland, Texas 79701
4. Location of Well UNIT LETTER <u>L</u> <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>990</u> FEET FROM THE <u>East West</u> LINE, SECTION <u>8</u> TOWNSHIP <u>18-S</u> RANGE <u>35-E</u> NMPM.
15. Elevation (Show whether DF, KT, GR, etc.) 3915.6 GR

7. Unit Agreement Name
8. Farm or Lease Name State "AF"
9. Well No. 3
10. Field and Pool, or Wildcat East Vacuum W. C.
12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>
OTHER <u>Install Artificial Lift</u> <input checked="" type="checkbox"/>	OTHER <input type="checkbox"/>
PLUG AND ABANDON <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
CHANGE PLANS <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Electrify location and build pad for Mark 456 pumping unit.
2. Install pumping unit.
3. MIRUPU. Flow well until it dies. Install BOPE.
4. Pull approximately 5786' tubing and leave SN @ approximately 4000'.
5. Run pump and rods.
6. Install dual wellhead. RD PU.
7. Put well on pump.

Exhibit 11/1/76

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED <u>W. J. McClintock</u>	TITLE <u>Dist. Oper. Supt.</u>	DATE <u>10-12-76</u>
APPROVED BY _____	TITLE _____	DATE <u>10-18-1976</u>

CONDITIONS OF APPROVAL, IF ANY: