

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 87240
District II
811 South First, Artesia, NM 87210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
2040 South Pacheco, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised March 25, 1999

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, NM 87505

WELL API NO. 30-025-21183
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name: Goodwin SWD #31
8. Well No. # Unit E, Sec. 31 T18S-R37E
9. Pool name or Wildcat SWD:SA-Delaware-BS

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)	
1. Type of Well: Oil Well <input type="checkbox"/> Gas Well <input type="checkbox"/> Other salt water disposal	
2. Name of Operator AGUA	
3. Address of Operator P.O. Box 92090, Pasadena, CA 91109	
4. Well Location Unit Letter: E : 660 feet from the West line and 1980 feet from the North line Section 31 Township 18S Range 37E NMPM County Lea	
10. Elevation (Show whether DR, RKB, RT, GR, etc.) 3737 GR	

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK <input type="checkbox"/> PLUG AND ABANDON <input checked="" type="checkbox"/> TEMPORARILY ABANDON <input type="checkbox"/> CHANGE PLANS <input type="checkbox"/> PULL OR ALTER CASING <input type="checkbox"/> MULTIPLE COMPLETION <input type="checkbox"/> OTHER: <input type="checkbox"/>	SUBSEQUENT REPORT OF: REMEDIAL WORK <input type="checkbox"/> ALTERING CASING <input type="checkbox"/> COMMENCE DRILLING OPNS. <input type="checkbox"/> PLUG AND ABANDONMENT <input type="checkbox"/> CASING TEST AND CEMENT JOB <input type="checkbox"/> OTHER: <input type="checkbox"/>

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Tag BTM Plug @ 6900'

- RU wireline or pick up work string and set CIBP 4400'. If using wire line, dump 35' cement on top. If CIBP via tubing spot 50 sxs of cement. Tag
- Circulate hole with gelled brine and set 50 sxs plug 50-50 in and out of the liner top at 2841'.
- PU and set another 50 sxs plug at 1400'+-.
- PU and set 50 sxs plug at 350' (base of 13 3/8"). Perf @ 13 3/8 casing 50' below shoe - 50' in 50' out.
- PU and set 10 sxs. surface plug.
- Cut off well head. Install dry hole marker with proper ID. Cut off dead man. Clean up location.

Starting Date: On or before 11-10-00

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE James Abbott TITLE Manager DATE 9-13-00

Type or print name James Abbott Telephone No. (505) 393-6188

(This space for State use)

APPROVED BY _____ TITLE _____ DATE _____

Conditions of approval, if any:

POK = 2808472