

- 4) A 20 sack cement plug will be placed from 2678' to 2478' which is the base of the salt section.
- 5) A 20 sack cement plug will be placed from 1753' to 1553' which is the top of the salt section.
- 6) A 20 sack cement plug will be placed at the surface of the hole and a dry hole marker set.

The formation tops are as follows:

Top of Anhydrite	1427'
Top of Salt	1553'
Base of Salt	2478'
Top of Yates	2785'
Top of 7-Rivers	3496'
Top of Queen	3698'
Top of Grayburg	4011'
Top of San Andres	4301'
Top of Glorieta	5845'

RECEIVED
SEP 8 10 1985
HOLERS OFFICE