

UNITED STATES  
DEPARTMENT OF THE INTERIOR  
GEOLOGICAL SURVEY

SUBMIT IN TRIPLICATE  
(Other instructions  
verse side)

Form approved.  
Budget Bureau No. 42-R142i.

5. LEASE DESIGNATION AND SERIAL NO.

LC032233 - (A)

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME

8. FARM OR LEASE NAME  
BOWERS "A" FED. COM.

9. WELL NO.

33

10. FIELD AND POOL, OR WILDCAT

HOBBS GB/SA & BLINEBRY

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA

S29, T18S, R38E

12. COUNTY OR PARISH

Lea

13. STATE

N.M.

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT" for such proposals.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐

2. NAME OF OPERATOR  
HUMBLE OIL & REFINING COMPANY

3. ADDRESS OF OPERATOR  
P. O. BOX 1600, MIDLAND, TEXAS 79701

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.\*  
See also space 17 below.)  
At surface 800' FNL, 660' FWL, Sec. 29,  
T-18-S. R 38 E

14. PERMIT NO.

15. ELEVATIONS (Show whether DF, RT, GR, etc.)

3657 DF

16. Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF

FRACTURE TREAT

SHOOT OR ACIDIZE

REPAIR WELL

(Other)

PULL OR ALTER CASING

MULTIPLE COMPLETE

ABANDON\*

CHANGE PLANS

SUBSEQUENT REPORT OF:

WATER SHUT-OFF

FRACTURE TREATMENT

SHOOTING OR ACIDIZING

(Other)

REPAIRING WELL

ALTERING CASING

ABANDONMENT\*

(NOTE: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)\*

Plugging procedure:

1. Displace 7" casing with mud.
2. Tag plug and spot 100' additional cement.
3. Cut and pull 7" casing from 2560'.
4. Cut and pull 9-5/8" casing from 1889'.
5. Run tubing to 1400' and spot 100' cement plug.
6. Spot 100' plug across 13-3/8" shoe @ 416'.
7. Spot 20' plug @ surface.
8. Cut off head and install marker.

Plugged & Abd 10-3-72

NOTE: All plugs displaced with mud.

18. I hereby certify that the foregoing is true and correct

SIGNED

TITLE

THE POOL COMPANY

DATE

(This space for Federal or State office use)

APPROVED BY

TITLE

CONDITIONS OF APPROVAL, IF ANY:

APPROVED

JAN 12 1973

J. L. GORDON  
REGIONAL DISTRICT ENGINEER