

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION

P. O. BOX 2088

SANTA FE, NEW MEXICO 87501

C+2 - NMOC-D- P.O. Box 1980 1 - Foreman
Hobbs, NM 88240 1 - WIO's
1 - Engr. *pws* 1 - File

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Getty Oil Company	8. Farm or Lease Name H.D. McKinley
3. Address of Operator P.O. Box 730 Hobbs, NM 88240	9. Well No. 10
4. Location of Well UNIT LETTER <u>B</u> <u>405</u> FEET FROM THE <u>North</u> LINE AND <u>2272</u> FEET FROM THE <u>East</u> LINE, SECTION <u>30</u> TOWNSHIP <u>18-S</u> RANGE <u>38-E</u> N.M.P.M.	10. Field and Pool, or Wildcat Blinebry
15. Elevation (Show whether DF, RT, GR, etc.) 3657 GR	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Acidize</u> <input checked="" type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up pulling unit.
2. P.O.H. with rods and tubing.
3. R.I.H. with tubing and packer.
4. Spot converter over perfs and let soak 24 hours.
5. Acidize well with 2,000 gals of acid.
6. Swab well back.
7. Put well back on production to clean up.
8. Squeeze inhibitor into formation.
9. Place back on production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED *[Signature]* TITLE Area Superintendent DATE October 8, 1981

APPROVED BY Jerry Sexton TITLE Dist 1, Supv DATE 1981

CONDITIONS OF APPROVAL, IF ANY: