

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-10  
Revised March 25, 199

DISTRICT I  
1625 N. French Dr., Hobbs, NM 88240  
DISTRICT II  
811 South First, Artesia NM 88210  
DISTRICT III  
1000 Rio Brazos Rd., Aztec, NM 87410  
DISTRICT IV  
2040 South Pacheco, Sante Fe, NM 87505

OIL CONSERVATION DIVISION

P.O. Box 2088  
Santa Fe, New Mexico 87504-2088

WELL API NO.  
**30-025-23541**

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.  
**8055**

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS)

1. Type of Well:

Oil Well ☐ Gas Well ☐ Other **injector**

2. Name of Operator

**Mobil Producing TX & NM, Inc.**

3. Address of Operator **P. O. Box 4358**

**Houston**

**TX 77210-4358**

8. Well No.

**139**

9. Pool name or Wildcat  
**Vacuum;Abo, North**

4. Well Location

Unit Letter **L** : **1980** Feet From The **south** Line and **860** Feet From The **west** Line

Section **14**

Township **17S**

Range **34E**

NMPH

**Lea**

County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☒ PLUG AND ABANDON ☐  
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐  
PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐  
COMMENCE DRILLING OPNS. ☐ PLUG & ABANDONMENT ☐  
CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103. (For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion)

**Repair Tbg/Pkr Leak and return to injection.**

- MIRU WSU, bleed off pressure and/or kill well.
- Install BOPE.
- Release Packer and POOH laying down.
- PU RIH w/Polycore Tbg, on/off tool and Pkr . Set Pkr @ +/- 8507'
- Release on/off tool, circulate Pkr fluid, Latch on to Pkr
- Perform MIT and return to injection.

hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE D. O. Howard

TITLE **Sr. Regulatory Specialist**

DATE **08/19/2002**

TYPE OR PRINT NAME **Dolores O. Howard**

TELEPHONE NO. **(713) 431-1792**

(This space for State Use)

APPROVED BY

DATE **SEP 06 2002**

CONDITIONS OF APPROVAL IF ANY