.....

Shearn Federal #1

:

#17 cont.

Spot 100' CL C cmt plug from 1050' to 950'. PU tbg to 50'.

Spot 50' CL C cmt plug at surface. Place permanent marker in cmt. Cln up loc.