

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
B-1306-1	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name Vacuum Grayburg San Andres
2. Name of Operator Texaco Inc.		8. Farm or Lease Name Vacuum Grayburg San Andres Unit
3. Address of Operator P. O. Box 728, Hobbs, New Mexico 88240		9. Well No. 32
4. Location of Well UNIT LETTER <u>L</u> . <u>30</u> FEET FROM THE <u>West</u> LINE AND <u>2630</u> FEET FROM THE <u>South</u> LINE, SECTION <u>1</u> TOWNSHIP <u>18-S</u> RANGE <u>34-E</u> NMPM.		10. Field and Pool or Wildcat San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 3999' (GR)		12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <u>Convert to Water Injection</u> <input checked="" type="checkbox"/>

SUBSEQUENT REPORT OF:

REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Pull rods & pump. Check TD w/tubing.
2. Clean out to total depth if necessary.
3. Wash perms. 4333'-4750' w/500 gals. 15% NE Acid. Swab.
4. Pull tubing.
5. Run 2 3/8" OD plastic coated tubing w/Pkr. Set pkr. @4280'.
6. Load Annulus w/inhibited water.
7. Commence water injection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Mgr. DATE 4/3/81

APPROVED BY Jerry Sexton TITLE Dist. L. Supr. DATE SEP 11 1981

CONDITIONS OF APPROVAL, IF ANY: