

SUMMARY WORKOVER PROCEDURE FOR THE MAX STATE #1

1. Perforate the Bone Spring interval from 8388'-84567' (total of 10 holes).
2. Acidize with 5000 gal 7.5% HCl NEFE acid with 25 ball sealers.
3. Fracture stimulate with 126,100# of 20/40 mesh sand.
4. Recover load and put well on pump.