## . STATE OF NEW MEXICO ENERGY AND MINERALS DEPARTMENT

מינים באירובריות וווויות וווויות וווויות	CI MII	11410
DISTRIBUTION		
SANTA FE		
FILE		
U.S.G.S.		
LAND OFFICE		
03554705	$\neg$	

## OIL CONSERVATION DIVISION

Form	C-1	03		
Revis	ed	10-	١-	73

DISTRIBUTION	P. O. BO	(2088			form C-103
SANTA FE	SANTA FE, NEW	MEXICO 8750	1		Revised 10-1-7
FILE				Sa. Indicate Type	of L name
U.S.O.S.	0+6 - NMOCD-P.O.			State XX	
LAND OFFICE	Hobbs, NM	88240	EF		F00
OPERATOR	l - Engr. l-Laura Richar	dson-Midland	1 - Filo	5, State Oil & Gas E-7653	s Lease No.
SUND	RY NOTICES AND REPORTS ON REPORTS ON REPORTS OF REPORTS OF REPORT OF PERMIT - " (FORM C-101) FOR SUC	WELLS ACK TO A DIFFERENT RE H PROPOSALS.)	SERVOIR.		
1. OIL X EAS WELL WELL	OTHER-			7. Unit Agreement	Name
2. Name of Operator		<del></del>		8. Farm or Lease	Name
Getty Oil Company				State AP	
P.O. Box 730 Hol	bbs, NM 88240			9. Well No.	
4. Location of Well			-	10. Field and Poo Vacuum Ab	ol, or Wildcat
UNIT LETTER L	1980 FEET FROM THE S	LINE AND6	60 FEET FROM	mmm	7777777777
· W	9 10	C	255		
THE LINE, SECT	110N 9 TOWNSHIP 18	S RANGE	SOE NMPM.		
	15. Elevation (Show whether	DF, RT, GR, etc.)		12. County	744444
				Lea	
16. Check	Appropriate Box To Indicate N	lature of Notice	Report or Oth	er Data	
	INTENTION TO:		-	REPORT OF:	
PERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK	$\Box$	ALVESI	ING CASING
$\overline{}$		COMMENCE DRILLING	H		· · · · · · · · · · · · · · · · · · ·
TEMPORARILY ABANDON			<del></del>	PLUG A	ND ABANDONMENT
PULL OR ALTER CABING	CHANGE PLANS	CASING TEST AND CEN			
Additionally	perforate X	OTHER		<del></del>	L_
17. Describe Proposed or Completed	Operations (Clearly state all pertinent deta	ails, and give pertinen	t dates, including	estimated date of s	starting any proposed
Work) SEE RULE 1703.					i.
1. TOH w/rods, pu	ump, and tha.	•			
2. Clean out with		:			
		*			•
		1			•
4. Perforate 5 1,	/2" csg. at 8891, 94, 96,	98, 8902, 04,	06, 11, 13,	, 22, 25,	
	5, 58, 62, and 65.				
5. TIH w/pkr.					
6. Spot 15% HCl a	across perfs.				
	8800' and set.			*	
	with 4000 gal. 15% NEFE.				
9. Swab back load					
	<b>4.</b>				
10. TOH w/pkr.					
11. TIH w/bit and	drill out CIBP to PBTD.			•	
12. Pull bit, run	rods, pump, and thg. and	return to prod	duction.		
	•				

TITLE Area Superintendent DATE August 8.
A-11/Cake

AUG 8 1983 HOSES CO.