

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.I.G.S.	
LAND OFFICE	
OPERATOR	

API #30-025-26973

5a. Indicate Type of Lease	
State ☒	Fee ☐
5. State Oil & Gas Lease No.	

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. CIL ☐ WELL ☐ GAS ☐ WELL ☐ OTHER- <u>INJECTOR</u>	7. Unit Agreement Name <u>N. HOBBS (G/SA) UNIT</u>
2. Name of Operator <u>SHELL WESTERN E&P INC.</u>	8. Form or Lease Name <u>SECTION 32</u>
3. Address of Operator <u>P. O. BOX 991, HOUSTON, TEXAS 77001</u>	9. Well No. <u>323</u>
4. Location of Well UNIT LETTER <u>G</u> <u>1370</u> FEET FROM THE <u>NORTH</u> LINE AND <u>1400</u> FEET FROM THE <u>EAST</u> LINE, SECTION <u>32</u> TOWNSHIP <u>18-S</u> RANGE <u>38-E</u> N.M.P.M.	10. Field and Pool, or Whichever <u>HOBBS (G/SA)</u>
15. Elevation (Show whether DF, RT, GR, etc.) <u>3638.66' GR</u>	12. County <u>LEA</u>

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data.

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK ☐	PLUG AND ABANDON ☐	REMEDIAL WORK ☐	ALTERING CASING ☐
TEMPORARILY ABANDON ☐	CHANGE PLANS ☐	COMMENCE DRILLING OPERATIONS ☐	PLUG AND ABANDONMENT ☐
PULL OR ALTER CASING ☐	OTHER <u>SQUEEZE & ACID TREAT</u> ☒	CASING TEST AND CEMENT JOBS ☐	OTHER ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1703.

1. Pull injection equipment.
2. Clean out to 4270'.
3. Set CICR @ 4265'. Squeeze San Andres perf's 4272' - 4332' w/50 sx Class "C" cmt + 2% CaCl₂ leaving 5' of cmt on top of the retainer.
4. Spot 250 gals 15% HCl-NEA from 4250' to 4000'. Flush acid w/50-100 bbls produced wtr. Spot 250 gals xylene from 4250' to 4000'. Pump 50-100 bbls produced wtr to flush xylene.
5. Acidize San Andres perf's 4062' - 4252' w/3900 gals 15% HCl-NEA.
6. Set packer @ #3995'.
7. Install injection equipment and resume injection.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED A. J. FORE TITLE SUPERVISOR REG. & PERMITTING DATE APRIL 24, 1985

APPROVED BY _____ TITLE _____ DATE _____