

- 34) TIH w/OS. Latch on. Jar. Rec BS, XO, OS, 1-3-1/2" DC.
- 35) TIH w/shoe. Wash over TOF. TOH. TIH w/OS. Latch on. Jar. No rec.
- 36) TIH w/OS. Latch on @ 8347'. Jar. TOH. No rec.
- 37) TIH w/shoe & 1 jt WP. Tag @ 8347'. Wash to 8368'. TOH.
- 38) TIH w/shoe. Wash over 8347-8371'. TOH.
- 39) TIH w/shoe to 7500'. Cut 8347-8372'. TOH. TIH w/OS. Latch on. Jar. TOH. No rec. LD tools.
- 40) TIH w/pkr. Set @ 8198'. A/perfs 8327-8429' w/2000 gals 20% NEFE & sd sqz w/2 drums inhibitor. Max P-350#. Min P-0#. AIR 4 BPM. ISIP Vacuum. TL 188 Bbls. TOH laying dn WS.
- 41) TIH w/MA-perf sub, SN, 2.875 tbg. Landed @ 8340'. TIH w/1.25 pmp & rds. Return to prod.

Test Prior - SI

Test After - Flowing 0 BO, 0 BW, 1009 MCF