

Slow Federal #2

4. RIH W/2-7/8 WS TO TOP OF CSG STUB. SPOT 100' CLASS "H" CMT PLUG IN AND OUT OF CSG STUB. PU TBG TO 4000, WOC OVERNIGHT. TAG TOP OF PLUG. PU TBG TO 7465.
5. SPOT 150' CLASS "H" CMT PLUG FROM 7465 TO 7315 (TOP OF BONE SPRING 7390). PU TBG TO 4157.
6. SPOT 100' CLASS "C" CMT PLUG FROM 4157-4057 ACROSS 8-5/8 CSG SHOE. PU TBG, WOC OVERNIGHT. TAG TOP OF PLUG. PU TBG TO 2638.
7. SPOT 100' CLASS "C" CMT PLUG INSIDE 8-5/8 CSG FROM 2638-2538 (TOP OF TANSIL 2588). PU TBG TO 950.
8. SPOT 100' CLASS "C" CMT PLUG FROM 950-850, (TOP OF RUSTLER 982). POH.
9. SPOT 50' CLASS "C" CMT PLUG AT SURFACE. PLACE PERMANENT MARKER IN CMT. CLN UP LOC.

RECEIVED

MAY 4 1984

O.C.D.
MOBBS OFFICE