

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☒ Fee ☐

5. State Oil & Gas Lease No.

06-1633

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name
2. Name of Operator Conoco Inc.	8. Farm or Lease Name Quail
3. Address of Operator P.O. Box 460 - Hobbs, New Mexico 88240	9. Well No. 1
4. Location of Well UNIT LETTER <u>A</u> <u>660</u> FEET FROM THE <u>north</u> LINE AND <u>660</u> FEET FROM THE <u>east</u> LINE, SECTION <u>22</u> TOWNSHIP <u>18S</u> RANGE <u>34E</u> NMPM.	10. Field and Pool, or Wildcat Austrip Bone Spring Underground Wellcamp
15. Elevation (Show whether DF, RT, GR. etc.)	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input checked="" type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

MIRU on 3/13/86. Tag cement on top of CIBP at 2264'. Circ w/mud.
Ran 2 3/8" hbq to 6077' spot 20 sxs cement. Pull up to 5961' &
Spot 40 sxs cement. WOC. Tag cement at 5607'. Pull up to
4833' & spot 40 sxs cement. Tag cement plug at 4720'. POOH
to 1900'. Spot 35 sxs cement, spot 35 sxs cement plug 100'
to surface. Cut off wellhead & install P&A marker.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED DF FINNEY

TITLE Administrative Supervisor

DATE June 6, 1988

APPROVED BY [Signature]

TITLE OIL & GAS INSPECTOR

DATE AUG 09 88

CONDITIONS OF APPROVAL, IF ANY: