

PROCEDURE CONT...

MESCALERO RIDGE "D" FEDERAL #1
Stimulate Bone Springs Formation

6. SPOT 2000 GALS 15% NEFE HCL W/ PARAFFIN DISPERSANT TO PKR @ 8300'. SET PKR W/ 15,000# COMP. FLUSH TO TOP PERF W/ 50 BBLS 2% KCL @ 3-5 BPM RATE, MAX WHTP 2500#. RD HALLIBURTON.
7. SWAB BACK ACID & LOAD WTR. RLSE PKR, LOWER TBG & LATCH ONTO BRP. POOH W/ 2 7/8" TBG, RDG PKR & RBP. RIH W/ MA, PF'D TBG SUB, SN & TAC ON 2 7/8" PROD TBG. SET TAC @ $\pm$ 8235'. REMOVE BOP. INSTALL WH. RIH W/ G.A., 2 1/2 X 1 1/2 X 24' RHBC ROD PUMP, 86 KD ROD STRING. SPACE OUT RODS. PLACE WELL ON PUMP.

FLUID SUMMARY:

15% NEFE HCL (5000 GALS)
10 GPT FE-1A (ACETIC ACID)
10 GPT FE-2L (CITRIC ACID)
2 GPT LOSURF-300 (SURFACTANT)

2 GPT PARASPERSE (PARAFFIN CONTROL)
5 GPT AS-5 (ANTI-SLUDGER)
1 GPT MUSOL-A (MUTUAL SOLVENT)