

UNITED STATES
DEPARTMENT OF THE INTERIOR
BUREAU OF LAND MANAGEMENT

SUBMIT IN TRIP
(Other instruction
verse side)

Form approved.
Budget Bureau No. 1004-0135
Expires August 31, 1985

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.
Use "APPLICATION FOR PERMIT—" for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☒ Water Injection		8. LEASE DESIGNATION AND SERIAL NO NMLC029489B
2. NAME OF OPERATOR OXY USA Inc.		9. IF INDIAN, ALLOTTEE OR TRIBE NAME
3. ADDRESS OF OPERATOR P.O.Box 50250 Midland, TX. 79710		10. UNIT AGREEMENT NAME
4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements. See also space 17 below.) At surface 2310 FNL 2310 FEL Sec 4 T18S R33E		11. FARM OR LEASE NAME Central Corbin Queen Ut
5. PERMIT NO. 300252970000S01		12. WELL NO. 214
6. ELEVATIONS (Show whether DP, RT, OR, etc.)		13. FIELD AND POOL, OR WILDCAT Corbin Queen, Central
7. SEC. T., R., N., OR BLE. AND SURVEY OR AREA Sec 4 T18S R33E		14. COUNTY OR PARISH Lea
8. STATE NM		15. STATE NM

Check Appropriate Box To Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT-OFF
FRACTURE TREAT
SHOOT OR ACIDIZE
REPAIR WELL

☐
☐
☐
☐

PTCL OR ALTER CASING
MULTIPLE COMPLETION
ABANDON*
CHANGE PLANT

☐
☐
☐
☐

SUBSEQUENT REPORT OF:

WATER SHUT-OFF
FRACTURE TREATMENT
SHOOTING OR ACIDIZING
(Other)

☐
☐
☐
☐

REPAIRING WELL
ALTERING CASING
ABANDONMENT*

☐
☐
☐
☐

(NOTE: Report results of multiple completion on Well Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

TD - 5000' PBTD - 4240' Perfs - 4163-4185'

- 1) MIRU PU. TOOH & LD pump & rods. NDWH, NUBOP. TIH w/ tbg & tag PBTD. TOOH w/ tbg.
- 2) TIH w/ RB & tbg & CO fill to PBTD. TOOH w/ RB & tbg.
- 3) TIH w/ pkr & 2-3/8" tbg & set @ 4070'. Acidize Queen perfs 4163-4185' w/2500 gal 15% NeFe HCl acid & flush w/2% KCl wtr.
- 4) Swab back load.
- 5) TOOH w/ pkr & tbg. TIH w/ injection pkr & 2-3/8" tbg & set @ 4070'. NDBOP, NUWH, RDP. Run csg integrity test.

18. I hereby certify that the foregoing is true and correct

SIGNED

David Stewart

TITLE

Prod. Acct.
915-685-5717

DATE

9/11/91

(This space for Federal or State office use)

APPROVED BY

TITLE

DATE

CONDITIONS OF APPROVAL, IF ANY:

*See Instructions on Reverse Side