

Page 2 - Cont'd.
Federal AG #2

7. POOH to 60'. Set surface plug to surface. W/20 sacks cement.
8. POOH, Cut off WH. Install a 4" dry hole marker to designate a plugged and abandoned location.