

**BASIN OPERATING COMPANY
SUITE 635 PETROLEUM BUILDING
ROSWELL, N.M. 88201**

**HUDSON FEDERAL 31 #2
990'FNL 790' FWL
SECTION 31, T18S R33E**

PLUGGING PROCEDURE

1. **TIH W/3500' RODS - TOH LAYING RODS DOWN - REPEAT FOR REMAINING RODS.**
 2. **TOH W/TBG. & PKR. - LAYING DOWN 1,900' (63 JOINTS) OF TBG.**
 3. **RU COMPUTALOG - DUMP 3 SKS. "H" CEMENT ON CIBP @ 5940'.**
 4. **SET CIBP @ 4,100' - DUMP 3 SKS. "H" CEMENT ON TOP OF CIBP**
 5. **TIH OPEN ENDED TO 3,643'+-**
 6. **RU DOWELL & SET PLUGS AS FOLLOWS:**

PLUG #1 - 10 SKS. "C" CEMENT - 3,643' - 3,543' - (50' BELOW & ABOVE 9 5/8" CSG.)
PLUG #2 - 10 SKS. "C" CEMENT - 450' - 350' - (50' BELOW 13 3/8' CSG.)
PLUG #3 - 5 SKS. "C" CEMENT - 10' - SURFACE
 7. **RD BOP - CUT OFF WELL HEAD - INSTALL DH MARKER**
-

EQUIPMENT STORAGE

RETURN RENTAL PACKER TO N.M. PACKERS

RETURN RENTAL BOP TO G & L TOOLS

**SEND RODS, TUBING & WELL HEAD TO TOOL PUSHERS SUPPLY
(WE WILL LEAVE PUMP JACK, FLOW LINES & TANK BATTERY IN PLACE UNTIL WE
DRILL THE NEXT WELL)**

VENDORS:

L&R	505 748 3835
DOWELL	505 748 1392
COMPUTALOG	505 397 2595
JIM'S WATER SERVICE	505 748 1352
WILBANK'S TRUCKING	505 746 6318
WEILER WELDING	505 746 4347
SWEATT CONSTRUCTION	505 748 1238
TOOL PUSHERS SUPPLY	505 745 9811