

**BASIN OPERATING COMPANY  
SUITE 635 PETROLEUM BUILDING  
ROSWELL, N.M. 88201**

**HUDSON FEDERAL 31 #2  
990' FNL 790' FWL  
SECTION 31, T18S R33E**

**PLUGGING PROCEDURE**

1. **TIH W/3500' RODS - TOH LAYING RODS DOWN - REPEAT FOR REMAINING RODS.**
  2. **TOH W/TBG. & PKR. - LAYING DOWN 1,900' (63 JOINTS) OF TBG.**
  3. **RU COMPUTALOG - DUMP 3 SKS. "H" CEMENT ON CIBP @ 5940'.**
  4. **SET CIBP @ 4,100' - DUMP 3 SKS. "H" CEMENT ON TOP OF CIBP**
  5. **TIH OPEN ENDED TO 3,643'+-**
  6. **RU DOWELL & SET PLUGS AS FOLLOWS:**  
  
**PLUG #1 - 10 SKS. "C" CEMENT - 3,643' - 3,543' - (50' BELOW & ABOVE 9 5/8" CSG.)**  
**PLUG #2 - 10 SKS. "C" CEMENT - 450' - 350' - (50' BELOW 13 3/8' CSG.)**  
**PLUG #3 - 5 SKS. "C" CEMENT - 10' - SURFACE**
  7. **RD BOP - CUT OFF WELL HEAD - INSTALL DH MARKER**
- 

**EQUIPMENT STORAGE**

**RETURN RENTAL PACKER TO N.M. PACKERS**

**RETURN RENTAL BOP TO G & L TOOLS**

**SEND RODS, TUBING & WELL HEAD TO TOOL PUSHERS SUPPLY  
(WE WILL LEAVE PUMP JACK, FLOW LINES & TANK BATTERY IN PLACE UNTIL WE  
DRILL THE NEXT WELL)**

**VENDORS:**

<b>L&amp;R</b>	<b>505 748 3835</b>
<b>DOWELL</b>	<b>505 748 1392</b>
<b>COMPUTALOG</b>	<b>505 397 2595</b>
<b>JIM'S WATER SERVICE</b>	<b>505 748 1352</b>
<b>WILBANK'S TRUCKING</b>	<b>505 746 6318</b>
<b>WEILER WELDING</b>	<b>505 746 4347</b>
<b>SWEATT CONSTRUCTION</b>	<b>505 748 1238</b>
<b>TOOL PUSHERS SUPPLY</b>	<b>505 745 9811</b>