

Emergency Equipment Requirements cont'd

9. Evacuation routes will be established prior to spudding of the well and discussed with all rig personnel.
10. Designated areas required:
 - a. Parking and visitor area.
 - All vehicles are to be parked at a pre-determined safe distance from the wellhead.
 - b. Safe briefing areas (see location plat attached).
 - Two safe briefing areas shall be designated on either side of the location at the maximum allowable distance from the well bore so they offset prevailing winds or they are at 180 degree angle if wind directions tend to shift in the area.
 - When the wind is from the prevailing direction, both safe briefing areas should be accessible.
 - Personal protective equipment (30 minute SCBA) will be kept at the safe briefing areas.