e) Set pony rods for space out.

•

.

Pumping Tee and piping per SOP. RDMO

15. Put production in the flowback tank to evaluate wells potential for facilities design and Eumont development evaluation.

-

u •_``;