

- B. Protective equipment for essential personnel:
 - a. Mark II Surviveair 30 minute units located in the dog house and at briefing areas, as indicated on well site diagram.
- C. H2S detection and monitoring equipment:
 - a. Two portable monitors positioned on location for best coverage and response. These units have warning lights and sirens when high levels of H2S is detected.
- D. Visual warning systems:
 - a. Wind direction indicators as shown on well site diagram.
 - b. Caution/Danger signs shall be posted on roads providing direct access to location.
- E. Mud program:
 - a. There is no known high pressure in this drilling area or known high concentrations of H2S that would necessitate any special drilling fluids.
- F. Metallurgy:
 - a. All drill stings, casings, tubing, wellhead, blowout preventers, drilling spool, kill lines, choke manifold and lines and valves shall be suitable for H2S service.
- G. Communication:
 - a. Radio communications in company vehicles including cellular telephone and 2-way radio.
- H. Well testing:
 - a. There will be no DST's on this well.