

## H2S CONTINGENCY PLAN

### Procedural Check List

#### Performed Each Tour by the Drilling Contract Personnel:

1. Check fire extinguishers to see that they have the proper charge:
2. Check pressure on breathing air cascade system to make sure they are charged to full volume.
3. Check pressure on drill pipe gauge on auxiliary panel for choke manifold to see that it is pressure communication with primary panel.

#### Performed Each Week by Drilling Contractor Personnel:

1. Blowout Preventer Drills.
2. Check nitrogen supply pressure on BOP accumulator stand-by source.

#### Performed Each Week by Callaway Safety Company Personnel:

Or

#### Daily on Supervisor:

1. Check each piece of breathing equipment to make sure that demand regulatory is working. This requires that the bottle to be opened and the mask assembly be put on tight enough so that when you inhale, you get air.
2. Check butane supply for burn pit for volume and to make sure 1" line is not plugged. Check automatic ignition system.
3. Check all SKA-PAC units for operation; demand regulator, escape bottle air volume, supply bottle air volume.
4. Check breathing equipment mask assembly to see that traps are loosened and turned back ready to put on.
5. Check pressure on breathing equipment air bottles to make sure they are charged to full volume.
6. Confirm pressure on all supply air bottles.
7. Perform breathing equipment drills with onsite personnel.