

## BLOWOUT PREVENTION EQUIPMENT

1. A kill line of ample strength and length will be laid to a safe point to allow pumping into the well in an emergency situation.
2. The closing unit should be located a safe distance from the well bore and positioned for maximum utilization based on the prevailing wind direction.
3. BOP equipment will be tested in accordance with standard company policy.