

### DRILL STEM TEST

1. Drill Stem Testing of Hydrogen Sulfide zones will be permitted only in daylight hours.
2. All non-essential personnel will be moved to "Safe Briefing Area".
3. Put on air masks before formation fluid are expected at the surface and continue "Masks On" until flares are lighted and work areas test no more that 10 ppm Hydrogen Sulfide and the area has been declared safe.