

OPERATIONS WHEN HYDROGEN SULFIDE IS DETECTED

1. At this time, the Texland Petroleum's Drilling Foreman will assess the situation, outline a program of control and assign duties. His instructions will be followed carefully. Success depends on how quickly, thoroughly and effectively each man does his assigned duties.
2. When severity of the situation has been determined, all personnel will be advised.
3. Personnel will develop a practice of watching out for each other when emergency conditions exist. Where possible, work should be done in pairs. When a Hydrogen Sulfide emergency exists, personnel should use the "buddy system" to prevent anyone from entering a contaminated area alone.
4. Hydrogen Sulfide gas discipline will be followed, when "Masks On" requirements exist. THERE ARE NO EXCEPTIONS.
5. Personnel will not remove the breathing equipment until tests indicate that the atmosphere is safe to breathe and "All Clear" is announced.
6. In the event of Sudden Gas Release, with no advance warning, personnel will be instructed to take the following general actions:
 - a. Hold breath - do not breathe
 - b. Put on protective breathing equipment
 - c. Help any person(s) in distress
 - d. Proceed to the designated "Safe Briefing Area" and secure instructions from Supervisor
 - e. DO NOT PANIC
 - f. If conditions warrant, the Driller will secure the rig, stop motion of the rig, and close the blowout preventers.
 - g. Schooling and instruction to all personnel on the site, concerning Hydrogen Sulfide Safety will be conducted by Callaway Safety Equipment Company instructors.

NOTE: PUT ON YOUR BREATHING EQUIPMENT BEFORE ATTEMPTING A RESCUE.

YOU TOO, CAN BECOME A VICTIM.