

W. H. BASKIN TELL NO. 3

Fill the hole with heavy mud and plug the bottom of 70 sacks of cement from 3693' to approximately 3458'. Set plug of 20 sacks from 3120' to 3050' (at the base of the a cement plug of 30 sacks from 1490' to approximately 1390 salt and in the bottom of the 8-5/8" casing). Pull all pos^{with} casing (approximately 900'). Spot cement plugs as follows to water sand from 700' to 800': 20 sacks, 828-800'; and 20 sacks 672'. Cement customary 4" pipe marker in the top of the hole sacks, leaving all 16" casing cemented in the hole. All mud and to be pumped in through tubing. The above confirms telephone communication and approval of your office on January 16, 1945.