

WELL WORK RECOMMENDATIONS
Proposals for Well Reconditioning and Subsurface Maintenance
Workovers, Expense DD's, PB's, and Conversions

Lease: BRIDGES STATE Well No. 6
Field: VACUUM (CARG.-S.A.)
County: LEA State: NEW MEXICO

RECOMMENDED PROCEDURE:

SEALERS WILL BE REQUIRED. RELEASE THE BALL SEALERS
AND INJECT 7,500 GALS OF FRESH WATER TREATED WITH 2 GALS
OF ADMALL PER 1,000 GALS OF WATER.

9. INSPECT AND RUN THE 2" CEMENT LINED INJECTION
TUBING (PER THE ATTACHED RECOMMENDATIONS) AND AN INJECTION
PACKER. LOAD THE TUBING CROWD-ANNULUS WITH FRESH
WATER TREATED WITH 10 GALS OF CORTON 2007 PER
1,000 GALS OF WATER. SET THE INJECTION PACKER
APPROXIMATELY 50' ABOVE THE LINER TOP.

10. RETURN THE WELL TO INJECTION.