

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.O.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
3-1506	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
TEXACO Inc.		Central Vacuum Unit
3. Address of Operator		9. Well No.
P. O. Box 728, Hobbs, New Mexico 88240		36
4. Location of Well		10. Field and Pool, or Willcat
UNIT LETTER P 660 FEET FROM THE South LINE AND 660 FEET FROM		Vacuum Grayburg
THE East LINE, SECTION 25 TOWNSHIP 17-S RANGE 34-E NMPM.		San Andres
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
3999' (GR)		Tea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Repair Water Flow	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Pull rods & pump. Install BOP. Pull tubing.
2. Set RBP @ 4000' & dump 25' Sand on plug.
3. Perforate 5 1/2" Csg. w/2-JS @ 1625'.
4. Set cement retainer @ 1650'. Cement perfs. @ 1625' w/200 Sx. Class 'H' Cement & circulate. Squeeze w/add'l 150 Sx. Cement. WOC. DOC & Test.
5. Clean out to TD. Install production equipment. Test & return to production.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Asst. Dist. Mgr. DATE 6-4-81

APPROVED BY [Signature] TITLE DATE
CONDITIONS OF APPROVAL, IF ANY: