

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease	
State ☒	Fee ☐
5. State Oil & Gas Lease No.	
E-1447	

SUNDY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO WELL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE APPLICATION FOR PRODUCE OR OTHER CHARTS FOR SUCH PROPOSALS.)

1. ☒ OIL WELL ☐ GAS WELL ☐ OTHER

2. Name of Operator
Atlantic Richfield Company

3. Address of Operator
P. O. Box 1710, Hobbs, New Mexico 88240

4. Location of Well
UNIT LETTER C 990 FEET FROM THE North LINE AND 1650 FEET FROM
THE West LINE, SECTION 32 TOWNSHIP 17S RANGE 34E NMPM.

15. Elevation (Show whether DF, RT, GR, etc.)
4076' GR

7. Unit Agreement Name

8. Form of Lease Name
State Vacuum Unit

9. Well No.
4

10. Field and Pool, or Wildcat
Vacuum Grayburg SA

12. County
Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK ☐	REMEDIAL WORK ☐
TEMPORARILY ABANDON ☐	COMMENCE DRILLING OPNS. ☐
PULL OR ALTER CASING ☐	CASING TEST AND CEMENT JOBS ☐
PLUG AND ABANDON ☐	OTHER ☐
CHANGE PLANS ☐	ALTERING CASING ☐
OTHER ☒ Run Liner & Cmt; Perforate, Acidize & Convert to WIW	PLUG AND ABANDONMENT ☐

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

TD 4708'. Presently completed in San Andres OH 4453-4708'. Propose to run liner & cmt. Perforate San Andres & acidize, convert to a WIW in the State Vacuum Unit Waterflood Project in accordance w/OCC Order No. R-5295 in the following manner:

1. Rig up, pull rods, pump. Install BOP & POH w/compl assy.
2. Clean out w/foam unit to 4708' TD.
3. Run caliper log.
4. Spot cmt for liner.
5. RIH w/350' of 3 1/2" OD NU 9,2# J-55 tbgs for liner w/TIW seal receptacle, reciprocate liner in cmt. Rel from liner & POH w/tbg. VOC.
6. Drill out cmt to PBD approx 4700'. Pressure test liner to 1000# 30 mins.
7. Perforate San Andres w/1 JSPF 4608-31'.
8. GIH w/2-3/8" OD EUE internally plastic coated tbgs w/locator sub & seal assy, set above perfs.
9. Fill 5 1/2" X 2-3/8" annulus w/corrosion inhibited fresh water, test annulus to 1000# for 30 mins, install pressure gauge on annulus.
10. Treat SA perfs 4608-31' w/2000 gals 15% HCL-NE acid cont'g iron sequestrant agent.
11. Install high pressure wellhead for water injection. Shut in. OCC to be notified when first water injection commences.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE Dist. Drlg. Supv. DATE 11/11/76

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: