

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs NM 88240

DISTRICT II
P.O. Drawer DD, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd., Aztec, NM 87410

OIL CONSERVATION DIVISION

P.O. Box 2088
Santa Fe, New Mexico 87504-2088

WELL API NO.

30-025-02904

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

B-1839

7. Lease Name or Unit Agreement Name

**EAST VACUUM GB/SA UNIT
TRACT 2738**

8. Well No.

002

9. Pool name or Wildcat

VACUUM GB/SA

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:

OIL
WELL ☒

GAS
WELL ☐

OTHER

2. Name of Operator

Phillips Petroleum Company

3. Address of Operator

4001 Penbrook Street, Odessa, TX 79762

4. Well Location

Unit Letter **F** : **1980** Feet From The **NORTH** Line and **1980** Feet From The **WEST** Line

Section **27** Township **17S** Range **35E** NMPM **LEA** County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

3938' GR

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☐

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: **CONVERT TO WATER INJECTION.** ☒

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. MIRU DDU. COOH LAYING DOWN RODS. NU BOP. RELEASE TAC AND COOH W/TBG (IF APPLICABLE).
2. RIH W/SLM. IF NEEDED, CLEAN OUT TO PBTD. IF OVER 50' OF FILL IS FOUND, MI & RU REVERSE UNIT.
3. RIH W/CASING SCRAPER TO 50' ABOVE OPENHOLE INTERVAL. COOH.
4. RIH W/PKR TO 50' ABOVE OPENHOLE INTERVAL. SET PACKER AND LOAD BACKSIDE TO VERIFY CASING INTEGRITY.
5. MIRU. PRESSURE TEST ALL SURFACE LINES TO 3500#. ACIDIZE WITH 3000 GALS 15% FERCHECK.
6. SWAB. COOH W/PKR AND WORKSTRING. RIH W/BAKER LOK-SET PKR ON 2-7/8" TBG. SET PKR @50' OF OPENHOLE INTERVAL. LOAD BACKSIDE W/INHIBITED BRINE, PRESSURE TEST TO 500 PSI., AND RECORD CHART.
7. ND BOP. NU INJECTION WELLHEAD. MONITOR INJECTION RATE AND PRESSURE UNTIL WELL STABILIZES.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *L. M. Sanders* TITLE SUPERVISOR, REG. AFFAIRS DATE 11/07/94

TYPE OR PRINT NAME L. M. SANDERS TELEPHONE NO. 915/368-1488

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

NOV 09 1994