Submit 3 Copies to Appropriate District Office

## State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

OIL CONSERVATION DIVISION DISTRICTI WELL API NO. P.O. Box 1980, Hobbs, NM 88240 P.O. Box 2088 Santa Fe, New Mexico 87504-2088 DISTRICT II P.O. Drawer DD, Artesia, NM 88210 5. Indicate Type of Lease STATE X FEE \_\_\_ SALT 6. State Oil & Gas Lease No. 1000 Rio Brazos Rd., Aztec, NM 87410 M-1424 SUNDRY NOTICES AND REPORTS ON WELLS ( DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A 7. Lease Name or Unit Agreement Name DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) TRUCKERS Type of Well: BRINE WELL 8. Well No. Name of Operator INTERNA 9. Pool name or Wildcat Address of Operator 4. Well Location 660 NORTH 666 Feet From The Feet From The Unit Letter LEA **NMPM** County Range Section 10. Elevation (Show whether DF, RKB, RT, GR, etc.) Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data 11. SUBSEQUENT REPORT OF: NOTICE OF INTENTION TO: ALTERING CASING PLUG AND ABANDON REMEDIAL WORK PERFORM REMEDIAL WORK PLUG AND ABANDONMENT **CHANGE PLANS** COMMENCE DRILLING OPNS **TEMPORARILY ABANDON** CASING TEST AND CEMENT JOB **PULL OR ALTER CASING** OTHER: OTHER:

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

SEE REVERSE SIDE

	tion above is true and complete to the best of my knowledge	and belief.	
SIGNATURE	en free	THE HOBBS MANAGER	DATE 12-5-90
TYPE OR PRINT NAME	PETE M. TURNE	5R	TELEPHONE NO. 397-494
(This space for State Use)	W.		
APPROVED BY	£ . ;	TITLE	DATE
CONDITIONS OF AFFROVAL, I	ANY:		

## ROWLAND TRUCKING COMPANY

A DIVISION OF

PHONE (505) 397-4994

## EUNICE RENTAL TOOL COMPANY

418 SOUTH GRIMES

HOSSE, NEW MEXICO 88240

PHONE [505] 393-9023

## PLUGGING PROCEDURE TRUCKERS 1

OBTAIN APPROVAL FROM O.C.D. ON PLUGGING PROCEDURE FORM C-103.

CALL D.C.D. AND GIVE APPROXIMATELY 24 HOOK NOTICE PRIOR TO STARTING PLUG JOB.

RIG-UP PULLING UNIT AND PULL 2 3/8 TUBING. LEAVE IN DERRICK. REMOVE SURFACE EQUIPMENT. TIE ON TO 5 1/2 CASIF. AND PULL. LAY DOWN ON ROWLF ID FLOAT.

RIG-UP WIRELINE TRUCK AND RUN 7 5/8 PLUG TO 1.850 FEET AND SET.

CALL O.C.D AND ADVISE THAT WE ARE GOING TO TAG PLUG AND CEMENT.

TAKE 1 JOINT 2 7/8 TUBING TO LOCATION AND START RUNNING TUBING TO TAG PLUG. AFTER PLUG IS TAGGED PULL 2 JOINTS 2 7/8 TUBING.

RIG-UP CEMENT TRUCK AND START PUMPING CLASS H CEMENT DOWN TUBING. PUMP IN 3 STAGES. VOLUME OF 30 SACKS CEMENT IN 7 5/8 CASING IS 100 FEET.

FIRST STAGE - PUMP 150 SACKS CEMENT BRINGING TOP OF CEMENT TO 1350. FLUSH AND PULL 8 DOUBLES OF TUBING.

SECOND STAGE - PUMP 150 SACKS CEMENT BRINGING TOP OF CEMENT TO APPROX. 850 FEET FLUSH AND PULL 10 DOUBLES OF TUBING.

THIRD STAGE - PUMP 250 SACKS CEMENT BRINGING TOP OF CEMENT TO SURFACE FLUSH AND PULL REMAINING TUBING.

PUT IN WELL MARKER AND CUT-OFF. RIG-DOWN UNIT.