

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-7

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease
State ☐ Fee ☒

5. State Oil & Gas Lease No.
B-2411

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER- Water Injection Well	7. Unit Agreement Name Lovington Paddock Unit
2. Name of Operator Texaco Producing Inc.	8. Farm or Lease Name Lovington Paddock Unit
3. Address of Operator P.O. Box 728, Hobbs, New Mexico 88240	9. Well No. 68
4. Location of Well UNIT LETTER <u>K</u> , <u>1980</u> FEET FROM THE <u>South</u> LINE AND <u>1890</u> FEET FROM THE <u>West</u> LINE, SECTION <u>6</u> TOWNSHIP <u>17S</u> RANGE <u>37E</u> N.M.P.M.	10. Field and Pool, or Wildcat Lovington Paddock
15. Elevation (Show whether DF, RT, GR, etc.) 3818 DF	12. County Lea

16. Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input checked="" type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <input type="checkbox"/>

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Pull tubing and packer.
2. Set CIBP @ $\pm 6100'$. Cap w/10 sxs cement.
3. GIH w/packer and locate the casing leak.
4. Load hole w/inhibited water.
5. Set a cement retainer above the leak and squeeze w/100 sxs class "H" cement.
6. Test to 500#.
7. Do not drill out retainer.
8. Shut well in. (TR-INC)

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED Ja Head TITLE Area Superintendent (397-3571) DATE March 13, 1987

ORIGINAL SIGNED BY JEFFRY SEXTON
DISTRICT I SUPERVISOR

APPROVED BY _____ TITLE _____ DATE MAR 20 1987

CONDITIONS OF APPROVAL, IF ANY: