

CAYLOR, C.S. SR. ESTATE 3  
LEA COUNTY, NEW MEXICO

5. Rerun submersible equip as before (see submersible pump recommendation dated 5/16/86).  
ND BOP. NU WH. RR. Start subpump & check rotation.
6. Place well on production test & monitor fluid level daily.