

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-73

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

5a. Indicate Type of Lease State <input checked="" type="checkbox"/> Fee <input type="checkbox"/>
5. State Oil & Gas Lease No. B-2354

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR.
USE "APPLICATION FOR PERMIT -" (FORM C-101) FOR SUCH PROPOSALS.)

OIL WELL <input checked="" type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER <input type="checkbox"/>	7. Unit Agreement Name Central Vacuum Unit
Name of Operator TEXACO Inc.	8. Farm or Lease Name Central Vacuum Unit
Address of Operator P. O. Box 728, Hobbs, New Mexico 88240	9. Well No. 63
Location of Well UNIT LETTER <u>G</u> <u>1980</u> FEET FROM THE <u>North</u> LINE AND <u>1980</u> FEET FROM THE <u>East</u> LINE, SECTION <u>31</u> TOWNSHIP <u>17-S</u> RANGE <u>35-E</u> NMPM.	10. Field and Pool, or Wildcat Vacuum Grayburg San Andres
15. Elevation (Show whether DF, RT, GR, etc.) 3977' (GR)	12. County Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
WILL OR ALTER CASING <input type="checkbox"/>	OTHER <input type="checkbox"/>	CASING TEST AND CEMENT JOBS <input type="checkbox"/>	OTHER <u>Deepen in San Andres</u> <input checked="" type="checkbox"/>

Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rigged up. Install BOP. Pull tubing & Submersible Pump.
2. Clean out & deepen to 4710'.
3. Packer set @ 4187'. Acidize open hole 4276'-4710' W/12,000 gals 15% NEFE Acid, 1800# Moth Balls, 1800# Rock Salt & 2 Drums Scale Inhibitor.
4. Install production equipment. Test & return to production.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

CO W.B. Loh TITLE District Operations Manager DATE 2-7-85
Eddie W. Seay
OVED BY Oil & Gas Inspector TITLE _____ DATE FEB 13 1985
DITIONS OF APPROVAL, IF ANY:

RECEIVED

FEB 12 1985

O.S.P.
HOBBS OFFICE