

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

NEW MEXICO OIL CONSERVATION COMMISSION

Form C-103
Supersedes Old
C-102 and C-103
Effective 1-1-65

5a. Indicate Type of Lease
State ☐ Fee ☒
5. State Oil & Gas Lease No.

SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. OIL WELL ☒ GAS WELL ☐ OTHER ☐	7. Unit Agreement Name
2. Name of Operator Exxon Company, U.S.A.	8. Farm or Lease Name Charles S. Alves
3. Address of Operator 1700 West Broadway, Andrews, Texas 79714	9. Well No. #1
4. Location of Well UNIT LETTER B 660 FEET FROM THE NL LINE AND 1980 FEET FROM THE EL LINE, SECTION 7 TOWNSHIP 19-S RANGE 35-E NMPM.	10. Field and Pool, or Wildcat Scharb-Bone Springs
15. Elevation (Show whether DF, RT, GR, etc.) 3910' R.D.B.	12. County Lea

16.

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK	☐
TEMPORARILY ABANDON	☐
PULL OR ALTER CASING	☐

PLUG AND ABANDON	☒
CHANGE PLANS	☐

OTHER ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK	☐	ALTERING CASING	☐
COMMENCE DRILLING OPNS.	☐	PLUG AND ABANDONMENT	☐
CASING TEST AND CEMENT JOB	☐		
OTHER	☐		

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

PULL 90 JTS 2 3/8 TBG. RUN 8 5/8 CUT. RETAINER ON TBG. SET RETAINER @ APPROX. 2500'.
LOAD 8 5/8 & 13 3/8 CSG ANNULUS W/PROD. WTR. JUST PRIOR TO SQUEEZE CEM. UNDER RETAINER.
WITH WORKSTRING STUNG INTO RETAINER, PRESSURE UP ON CSG-TBG ANNULUS TO 1000 PSI.
SQUEEZE CMT. INTERVAL UNDER RETAINER W/500 SKS CUT. PULL OUT AND CAP RETAINER W/25' OF CUT.
CIRCULATE HOLE W/9.5#/GAL. MUD LADEN BRINE. ESTABLISH FREE POINT OF 8 5/8 CSG. IF FREE POINT
IS ABOVE 1750', THEN PERFORATE @ 1800'. RUN WORKSTRING AND PUMP 75 SKS OF CEMENT INSIDE
AND OUTSIDE OF CSG. DISPLACE W/SUFFICIENT VOLUME TO LEAVE CMT. PLUG @ 1750' INSIDE 8 5/8 CSG.
CUT OFF 8 5/8 CSG & PULL. IF FREE POINT IS BELOW 1750', THEN CUT OFF 8 5/8" CSG & PULL.
SPOT A 100' CUT. PLUG FROM 1750-1850 W/75 SKS. SPOT ADDITIONAL CUT PLUGS THRU
TBG AS FOLLOWS:

A. 100' PLUG BELOW THE BALL VALVE AND ACROSS THE SURFACE CSG. SHOE FROM
345-445' W/75 SKS.

B. 10' PLUG AT SURFACE.

PUMP ALL CEMENT PLUGS DOWN W/9.5#/GAL MUD LADEN BRINE. TAG ALL PLUGS
W/TBG STRING TO VERIFY PLACEMENT.

RIG WELHEAD FOR ABANDONMENT AND INSTALL MARKER.

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNED [Signature] TITLE UNIT HEAD DATE 10-16-74

APPROVED BY Joe D. Ranney TITLE Dir. I. Supv. DATE NOV
CONDITIONS OF APPROVAL, IF ANY