

9. Acidize Wolfcamp perforations 9515' - 9852' w/6000 gals 15% retarded acid in 3 equal stages w/75# benzoic acid between 1st and 2nd stages and 100# benzoic acid between 2nd and 3rd stages.
10. Swab Abo and place on production.
11. Retrieve bridge plug from Wolfcamp.
12. Swab Wolfcamp and return to production.

RECEIVED

JUN 23 1971

OIL CONSERVATION COMM.
HOBBS, N. M.