

STATE OF NEW MEXICO
ENERGY AND MINERALS DEPARTMENT

NO. OF COPIES RECEIVED	
DISTRIBUTION	
SANTA FE	
FILE	
U.S.G.S.	
LAND OFFICE	
OPERATOR	

OIL CONSERVATION DIVISION
P. O. BOX 2088
SANTA FE, NEW MEXICO 87501

Form C-103
Revised 10-1-78

5a. Indicate Type of Lease	
State <input checked="" type="checkbox"/>	Fee <input type="checkbox"/>
5. State Oil & Gas Lease No.	
2-155-1	

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT - D" (FORM C-101) FOR SUCH PROPOSALS.)

1. <input checked="" type="checkbox"/> OIL WELL <input type="checkbox"/> GAS WELL <input type="checkbox"/> OTHER-		7. Unit Agreement Name
2. Name of Operator		8. Farm or Lease Name
Texaco, Inc.		U. N. '0' St. NCT-1
3. Address of Operator		9. Well No.
P. O. Box 728, Hobbs, New Mexico 88240		16
4. Location of Well		10. Field and Pool, or Wildcat
UNIT LETTER <u>H</u> <u>990</u> FEET FROM THE <u>East</u> LINE AND <u>1920</u> FEET FROM		Vacuna Glorieta
THE <u>North</u> LINE, SECTION <u>36</u> TOWNSHIP <u>17-S</u> RANGE <u>34-E</u> NMPM.		
15. Elevation (Show whether DF, RT, GR, etc.)		12. County
4002' (DF)		Lea

Check Appropriate Box To Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

SUBSEQUENT REPORT OF:

PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	OTHER <input checked="" type="checkbox"/> Repair Water Flow	CASING TEST AND CEMENT JOB <input type="checkbox"/>	

17. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

1. Rig up. Pull rods & pump from Glorieta string. Install BOP. Pull tubing.
2. Set RBP in Glorieta string @ 5000'. Load string w/2% KCl water.
3. Set RBP @ 5000' in abandoned 2 7/8" csg. string & dump 20' sand on plug.
4. Perforate abandoned 2 7/8" csg. string & 8 5/8" csg. w/2-holes @ 1555'.
5. Cement 11 3/4" x 8 5/8" csg. Annulus w/500 sx. class 'H' cement & circulate. Squeeze w/addl. 200 sx. class 'H' cement. WOC. Run temperature survey if cement does not circulate. WOC a total of 18 hrs. DOC & test. Pull RBP from both strings.
6. Run production equipment. Test & return to production.

THE ABOVE INFORMATION IS TRUE AND COMPLETE TO THE BEST OF MY KNOWLEDGE AND BELIEF
24 10/15/81

18. I hereby certify that the information above is true and complete to the best of my knowledge and belief

SIGNED [Signature] TITLE Asst. Dist. Supt. DATE 1/21/81

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY: